

# Padlock Usage

## General Usage



**1** If the lock is in the locked state, insert a charged and coded OneKEY into the IR port on the bottom of the lock and press the button. Hold the key in place until the confirmation beep & the LED goes out.



**2** Once the key has beeped in confirmation pull the shackle out from the lock body.



**3** Insert the shackle through the object that will be secured.



**4** Swivel the lock body so that the hole is aligned with the shackle.

## Weather Sleeve Installation Steps



**5** Close the padlock to secure the object. To open the padlock, use a charged and coded OneKEY as shown in step 1. Pull on the lock body to ensure that it is locked.



**6** Insert the shackle into the bottom of the cover.



**7** Carefully fit the cover around the top of the lock body.  
**Note:** Do NOT pull on the separate tab to prevent tearing the cover.



**8** Continue carefully working the cover down onto the lock body.

## Padlock Usage



**9** Work the cover fully down onto the lock body so that the cover sits against the top of the lock as shown.



**10a** If using a padlock with an anti-cut cover and its corresponding weather cover, ensure that when installing, the logos on the padlock and weather cover are facing in the same direction.



**10b** Ensure that the cover fully sits on the padlock as shown.



**11** Insert the plug at the end of the tab into the IR port to protect the port from moisture and debris.



**12** To remove the cover, unplug the tab and begin carefully rolling the cover up the lock body.



**13** Continue rolling the cover up the lock body.



**14** Remove the cover.



**15** Turn the cover rightside out to reuse the cover on another lock.

## Padlock Usage

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.