

## ZC1901 Installation



- 1 Use the provided alcohol wipe to clean the area where the ZC1000 base will be placed. Allow it to dry completely.



- 2 Feed the cable from the base through the fixture.



- 3 Peel the clear film from the 4 adhesives on the bottom of the base.



- 4 Place the base where desired and apply pressure for at least 10 seconds.




- 5 Place the ZC1901 plate onto the base so that the orange alignment indicator is visible through the hole in the plate.



- 6 Slightly rotate the plate clockwise to lock it into place on the base.



- 7 Place the item that will be displayed onto the plate.  
**Note:** If the item will be powered, the charging cable can be routed through the hole in the plate.



- 8 Align the tabs on the cover with the gaps in the plate.

## ZC1901 Installation



- 9 Rotate the cover into the locked position.



- 10 To remove the cover and demonstrate the displayed product, insert a charged and coded OneKEY into the port on the side of the plate. Press the button on the key.




- 11 Rotate and lift the cover free from the plate.

### Removal/Remerchandising



- 12 To remove the cover, insert a charged and coded OneKEY into the port on the side of the plate. Press the button on the key.



- 13 Rotate and lift the cover free from the plate.



- 14 To remove the plate from the base, place a magnet key onto the flat spot on the side of the base.



- 15 Slightly rotate the plate to the unlatched position.

## ▶ ZC1901 Installation

---



- 16 Lift the plate free from the base.